


## Practical case: Low-Side Transistor Relay Switch




Master Analog Electronics by building a relay driver circuit. Use an NPN Transistor to safely switch high-voltage loads and protect logic chips from spikes.

---

## Practical case: Intrusion alarm by wire break

# Intrusion alarm by wire break




Master Analog Electronics by building a wire-cut alarm. Learn how a Transistor switch triggers an LED instantly when a security loop is broken.

---

## Practical case: Slow turn-off timer

# Slow turn-off timer




Master Analog Electronics by building a fade-out LED circuit. Use a Transistor and capacitor to create a 5-second delay timer that mimics car interior lighting.

---

## **Practical case: Simple audio amplifier**

# Simple audio amplifier




Master Analog Electronics by building a Class A amplifier. Use an NPN Transistor to boost weak audio signals and observe voltage gain with phase inversion.

---

**Practical case: The transistor as a light switch**

# The transistor as a light switch




Master Analog Electronics by building a Transistor switch circuit. Learn to control high-current loads like LEDs and measure saturation voltage drops.

---

## **Practical case: Linear supply voltage smoothing**

# Linear supply voltage smoothing



Linear supply voltage smoothing

Master Analog Electronics by building a power supply filter. Test how Capacitor values reduce voltage ripple from 5V to 0.5V, ensuring stable DC for circuits.